

Spare parts for dial indicator 2324 series



Part NO.	Code	Description
1	SP-DUST CAP-2324	Dust cap
2	SP-DIAL-FAGGING-2324	Protecting jacket
3	SP-POINT-RK-2324	Contact point
4	SP-MAIN GEAR-2324	Main gear
5	SP-DIAL-GLASS-2324	Dial glass