


Spare parts for dial test indicator 2880



| Part NO. | Code | Description |
|----------|----------------------|---|
| 1 | SP-BP-2880 | Dial for 2880-02 |
| 2 | 6284-45 | Contact point for 2880-02R(ruby) |
| 3 | SP-DIAL ASSY-2880 | Assy for 2880-02 |
| 4 | SP-BEARING ASSY-2880 | Bearing assy for 2880-02(include the nut) |